

Ceiling / Parasol / Gazebo Mount

User Instructions - Please keep for future reference

U3-CMB

Read **ALL** instructions before installing this unit

- **DO NOT** move the unit when attached to an electric heater. Wait until the heater is completely cool and disconnect the heater from this unit before attempting to move it.
- Position the unit and heater at least 1m away from highly combustible materials, such as furniture, trees, leaves, dry grass and bushes.
- The heater **MUST BE** a minimum of 1.8m away from the ground when installed on this unit.
- The heater **MUST NOT BE** installed on this unit with the heating element(s) pointing upwards towards the ceiling. The heater element **MUST** be facing the area it is to heat.
- **DO NOT** install this unit and heater in the immediate surroundings of a bath, shower, swimming pool or hot tub.
- When locating the ceiling bracket into the chosen ceiling joist, ensure the ceiling is in good condition and suitable to hold this type of product.
- This unit is only suitable for use with the following Heatmaster branded models: U3-R/G20 & U2BS-R/G24

IMPORTANT! – Carefully remove any packaging before use, but retain the safety instructions.

These instructions form part of the product.

Please take note of all of the safety warnings listed in these instructions.

Please read these instructions in their entirety and retain them for future reference.

These instructions should be stored with the product.

This product is for domestic use **ONLY** and should not be used commercially for camping or for contract purposes.

Failure to adhere to these instructions could result in property damage, personal injury or death.